



 DC515 XX P2/BS



x1



x1



x1




x2

CR2032







x1




GB Contents **DE** Inhalt **FR** Contenu **NL** Inhoud **F** Sisältö
DK Indhold **IT** Contenuto **ES** Contenido **PT** Conteúdo
GR Περιεχόμενα **SE** Innehåll

GB Getting started **DE** Erste Schritte **FR** Démarrage **NL** Aan de slag
F Aloitusopas **DK** Kom i gang **IT** Operazioni preliminari **ES** Para empezar
PT Para começar **GR** Πρώτα βήματα **SE** Kom igång






x1



x1



CR2032








15mm







GB Optional features DE Optionale Funktionen FR Options disponibles NL Opties
 FI Valinnaiset ominaisuudet DK Valgtrier funktioner IT Funzionalità opzionali
 ES Opciones disponibles PT Funções opcionais GR Προαιρετικές λειτουργίες πρόσθετων
 SE Möjliga funktioner



GB Linking DE Einlernen
 FR Programmation NL Verknüpfung
 FI Linkittäminen DK Forbinde
 IT Collegamento ES Enlace PT Pro-
 gramação GR Ούδωση SE Länkning



	Hello	Ding Dong	Westminster	Marimba	Piano	Bell	Telephone	Soft Alert
	•	•					•	•
	•	•	•	•			•	•
	•	•	•	•	•	•	•	•



		3Hrs 			6Hrs
		9Hrs 			12Hrs



GB Trouble shooting DE Fehlerbehebung FR Dépannage NL Probleemoplossing
 FI Vianmääritys DK Problemløsning IT Risoluzione dei problemi ES Solución de
 problemas PT Resolução de problemas GR Αντιμετώπιση προβλημάτων SE Felsökning

livewell.honeywell.com



32305357-001 Rev.B