

HÅNDBOK

Bruksanvisning for Beha oljeovn
ORC 1015



Kjære kunde

Denne håndboken gjelder for oljeovnen ORC 1015.

For å sikre høyest mulig produktkvalitet har Beha valgt å bruke Nemko for sertifisering av oljeovnen. Dette for å ivareta din sikkerhet på best mulig måte.

Utvikling av nye produkter er en kontinuerlig prosess. Vi tar derfor forbehold om endringer av funksjoner og eventuelle trykkfeil.

Les håndboken nøye og ta vare på den. Vær spesielt oppmerksom på produsentens merknader og råd for sikker bruk.

Vi håper du blir fornøyd med den nye oljeovnen din.

Med vennlig hilsen
Beha Elektro AS

PS: Vi gjør oppmerksom på at oljeovnen som er beskrevet i denne håndboken kun er beregnet for bruk i private hjem.

Dette produktet er bare egnet til sporadisk bruk i godt isolerte rom.

**Les denne veiledning nøye,
og ta vare på den til senere bruk.**



For å unngå brann eller personskader bør man følge våre sikkerhetsregler.

Les hele bruksanvisningen før ORC 1015 tas i bruk.

- Før bruk fjernes all emballasje og benene monteres. Se side 7. Tilkoble ikke strøm før all montering er ferdig.
- Oljeovnen skal kun brukes som tilleggsvarme innendørs.
- Ovnens må slås av når man **IKKE** er til stede.
- Slå av bryteren og fjern støpslet fra stikkontakten når ovnen ikke er i bruk og ved rengjøring.

ADVARSEL! Ovnens blir varm under bruk. Ikke berør varme overflater. Vær ekstra oppmerksom ved tilstedeværelse av personer med reduserte fysiske, sensoriske eller mentale evner, personer med manglende erfaring og kunnskap, eller barn.

- Oljeovnen skal stå på et plant gulv. Den skal ikke brukes på myke overflater da den kan velte.
- Må ikke brukes på plasser der det er støv, damp, gass, bensin, maling eller hvor andre brannfarlige varer er lagret (eks. garasje). Må ikke brukes i eksplosjonsfarlige områder etc.
- Ved oljelekkasje skal ovnen ikke brukes.
- Må ikke brukes i nærheten av badekar, vaskeområder eller svømmebasseng. Ovnens skal kun brukes i tørre rom for å unngå elektrisk støt, kortslutning og brann.

- Oljeovnen kan brukes av barn fra 8 år og oppover, personer med reduserte fysiske, sensoriske eller mentale evner, personer med manglende erfaring og kunnskap hvis de får tilsyn eller instruksjoner for bruk av produktet. Instruksjonen må gis på en sikker måte slik at farene involvert er forstått. Barn skal ikke leke med ovnen. Rengjøring og vedlikehold skal ikke gjøres av barn uten tilsyn.
- Skal ikke brukes i rom med barn, dyr eller personer med funksjonshemninger med mindre det er en ansvarlig person tilstede.
- Skal ikke brukes i rom hvor det oppholder seg personer som ikke kan forlate rommet på egenhånd.
- **ADVARSEL!** Barn under 8 år skal holdes unna ovnen med mindre de er kontinuerlig overvåket.
- Ikke senk ovnen i vann eller væske for rengjøring.
- Ikke dekk til produktet under bruk eller kort tid etter at den er slått av da det kan medføre brann.
- Skal ikke plasseres rett under en stikkontakt.
- Stikkontakten skal være synlig og tilgjengelig.
- Ved rengjøring, flytting eller når ovnen ikke er i bruk gjøres den strømløs ved å slå av bryteren for så å trekke ut støpselet fra stikkontakten. **Ikke** dra i kabelen men ta tak rundt støpselet.

MERK! Ikke koble til strømforsyning om ovnen eller strømledningen er skadet. Hvis du er i tvil, kontakt din leverandør.

- Er kabelen eller støpslet ødelagt skal ovnen ikke brukes. Kabelen må ikke komme i berøring med de varme overflatene på ovnen under bruk.
- Kabelen skal ikke tildekkes av matter eller lignende. Kabelen skal ligge slik at den ikke blir tråkket på.
- Påse at ingen fremmede objekter er plassert i/på ribber da det kan forårsake elektrisk feil, brann eller ødelagt ovn.
- Ikke ta på ovnene med våte hender.
- Må ikke ligge på siden. Om oljeovnen skulle velte, koble den fra strømmettet og la den avkjøles.
- Ikke bruk en programmerer, timer, fjernkontrollsystem eller andre enheter for å slå på og av produktet automatisk, da dette vil kunne innebære brannrisiko hvis ovnen er dekket til eller plassert feil.
- Luftinntaket over kabelvinnen må ikke blokkeres.
- Ovnene skal ikke repareres, demonteres eller modifiseres fordi den ikke har utskiftbare deler innvendig.

**Advarsel**

For å unngå overopphetning må oljeovnen ikke tildekkes.


Elektrisk tilkobling og bruk

Før tilkobling av oljeovnen, påse at nettspenningen er 220-240V ~ 50 Hz.

Oljeovnen tilkobles stikkontakt i det rommet som den brukes i. Bruk ikke skjøteledning, da det kan medføre brannfare.

Avstander


Oljeovnen brukes unna hindringer som påvirkes av varme f.eks. møbler, gardiner, eller andre brennbare gjenstander. Anbefalt klaring er 1 meter over og til sidene.



Montering av ben:

- Sjekk at du har alle delene. Se tabell under.
- U-bøylen tres rundt varmeribbene (1 og 2), benene plasseres på bøylen og skrues fast med 2 vingemuttere (3).

ORC 1015



Viktig
Beina skal monteres
med vinkelen bort
fra ovnen

Beskrivelse av deler

	 Ben	 Bøyler	 Vingemutter
ORC1015	2	2	4

Stell og vedlikehold

- Fjern strømtilkoblingen og avkjøl oljeovnen før rengjøring.
- Rengjør utsiden med en fuktig klut.
- Bruk aldri etsende rengjøringsmidler eller sett oljeovnen i vann.

Spesifikasjoner

- Strømforsyning 220-240V ~ 50Hz
- Effekt Se tabell
- Strømledning 1,8M
- Nettovekt Se tabell
- Isolasjon Klasse 1
- Mål (L x B x D) cm Se tabell

Modell	Watt	Regulering av watt	Nettovekt	Mål (L x B x H)
ORC1015	1000	400 / 600 / 1000	7,48 kg	29,5x28x64 cm

Effektvelger

Oljeovnen har tre effektinnstillinger.

Trinn 1 gir laveste effekt. Trinn 2 gir mellomste effekt.

Maksimal effekt oppnås ved at bryter settes på 3.

Bruk av oljeovnen

Sett pluggen i stikkontakten. Sett effektvelgeren i stilling for maksimal effekt og vri termostatrattet med klokka til den stopper.

Oljeovnen gir nå maksimal effekt og vil starte å varme.

Når du har oppnådd den ønskede temperaturen dreies termostat-rattet mot klokka inntil indikatorlampen for termostaten slukkes.


Vær oppmerksom på

- Et rødt lys over termostaten lyser når elementene er innkoblet.
- Sørg for god ventilasjon rundt oljeovnen. Hvis ikke vil dette kunne influere på termostaten og dens virkemåte.
- Oljeovnen har overopphetningssikring. Denne vil koble ut strømmen til elementene ved unormal høy temperatur.
- Skulle oljeovnen velte vil en veltesikring koble ut strømmen til elementene.

Termostat



Effektvelger





Avfallshåndtering

Dette apparatet er merket i samsvar med EU-direktiv 2014/30/EU, 2014/35/EU og 2012/19/EU om håndtering av elektrisk og elektronisk avfall (Waste Electrical and Electronic Equipment-WEEE). Forsikre deg om at dette produktet blir avhendet på korrekt vis, slik at det ikke kan utgjøre noen helse- eller miljø risiko.

Symbolet  på produktet eller på dokumentene som følger med det, viser at dette produktet ikke må behandles som husholdningsavfall. Lever det til et autorisert mottak for resirkulering av elektrisk og elektronisk utstyr. Avhenting må skje iht. de lokale renovasjonsforskriftene. For nærmere informasjon om håndtering, kassering og resirkulering av dette produktet, kontakt kommunen, renovasjonsvesenet eller forretningen der du anskaffet det.

BEHA

BEHA ELEKTRO AS, 3940 PORSGRUNN
Tlf.: 35 51 62 50 Fax: 35 51 62 60 Ordre: 35 51 62 70
e-post: post@beha.no

www.beha.no

BEHA

MANUAL

Instructions for Beha portable liquid radiator
ORC 1015



Dear customer

Congratulations on your new Beha portable liquid radiator. You have purchased a modern high quality product. In addition, it is easy to operate.

This manual applies to model ORC 1015.

New product development is a continuous process. We therefore subject to change of functions and printing errors.

Read the manual carefully and take care of it. Please keep in mind the manufacturer's instructions and advice for safe operation.

We hope you are satisfied with your new oil heater.

Sincerely,
Beha Elektro AS

PS: Please note that the portable liquid radiator as described in this handbook is intended for use in private homes.

This product is only suitable for occasional use in well insulated spaces.

**Read this manual carefully,
and preserve it for future use.**



When using any electrical appliance, basic precautions should always be followed to reduce the risk of fire, electrical shock and injury to persons , including the following:

1. Read all instructions before using heater.
2. This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. Keep combustible materials such as furniture, pillows, bedding, papers, clothes and curtains at least 3 feet (0.9m) from the heater. Allow heater to cool before moving and then use the built-in handle for easy movement.
3. Extreme caution is necessary when heater is used by or near children and whenever heater is left unattended.
4. Always unplug the heater when it is not in use.
5. Do not operate any heater with a damaged cord or plug, or after the heater malfunctions, or has been dropped or damaged in any manner. Return heater to the manufacturer for examination, electrical or mechanical adjustment, or repair.
6. Do not use heater outdoors. This product is intended for normal household indoor use only.
7. This heater is not intended for use in bathrooms, laundry areas or similar moist indoor locations. Never locate heater where it may fall into a bathtub or other water container.
8. Do not run power cord under carpeting. Do not cover cord with throw rugs, runners or the like. Arrange cord away from traffic areas and where it will not be tripped over.
9. To disconnect heater, set controls to OFF, then remove plug from outlet.
10. Keep this heater clean. DO NOT allow foreign objects to enter any ventilation or exhaust opening as this may cause electric shock, or fire, or damage the heater.
11. To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
12. A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable liquids are used or stored.

13. Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
14.  Warning: In order to avoid overheating, do not cover the heater.
15. Do not use this heater in the immediate surroundings of a bath, a shower or a swimming pool.
16. The heater must not be located immediately below a socketoutlet.
17. If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard. Use of an extension cord is not recommended. However, if it is absolutely necessary ensure the cord is short as possible (long cords coiled up can overheat, as well as cause tripping accidents).
18. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

**Correct Disposal of this product**

This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

20. This heater is filled with a precise quantity of special oil. Repairs requiring opening of oil-container are only to be made by the manufacturer or his service agent who should be contacted if there is an oil leak. When scrapping the heater, follow the regulations concerning the disposal of oil.
21. Children of less than 3 years should be kept away unless continuously supervised. Children aged from 3 years and less than 8 years shall only switch on/off the appliance provided that it has been placed or installed in its intended normal operating position and they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children aged from 3 years and less than 8 years shall not plug in, regulate and clean the appliance or perform user maintenance.
22. CAUTION — Some parts of this product can become very hot and cause burns. Particular attention has to be given where children and vulnerable people are present.
23. This heater is filled with a precise quantity of special oil. Repairs requiring opening of oil-container are only to be made by the manufacturer or his service agent who should be contacted if there is an oil leak. When scrapping the heater, follow the regulations concerning the disposal of oil.

**Caution**

To avoid overheating, do not cover the heater.

NOTE! Do not connect the power supply if oil heater or power cord is damaged. If in doubt, contact your supplier.


Electrical connection and use

Before connecting the portable liquid radiator, ensure that the main voltage is 220-240V~ 50Hz.

The portable liquid radiator connected socket in the room as it is used in. Do not use extension cords as this may result in fire.


Distances

The portable liquid radiator should be away from furniture, curtains or other flammable objects. Recommended clearance is 1 meter above and to the sides.




Mounting the legs:

- Make sure you have all the parts. See table below.
- Make sure the heater is unplugged and the power switch is in the "0" OFF position.
- **TURN THE HEATER UPSIDE DOWN**
- Attach the wheel caster onto the heater as the picture shows. One U plate is fixed between the first & second fin, and the other one is fixed between last two fins. Fix the casters to the vertical axis of both the wheel holding plates.
- Insert the butterfly nuts and tighten them securely. **TURN THE HEATER UPRIGHT.**
- Your heater is now ready to use.



Part description

	 Wheel caster	 U plate	 butterfly nut
ORC1015	2	2	4

Care and Maintenance

- Remove power connection and cooling portable liquid radiator before cleaning.
- Clean the outside with a damp cloth.
- Never use abrasive cleaners or put oil heater in water.

Specifications

- Power supply 220-240V~ 50Hz
- Power See table
- Power cord 1,8M
- Net Weight See table
- Insulation class 1
- Dimensions (LxWxD)cm See table

Model	Watt	Regulating watt	Net weight	Dimensions (L x W x D)
ORC1015	1000	400 / 600 / 1000	7.48 kg	29,5x28x64 cm


Insert the plug into the suitable wall outlet.


- 1) Never use the unit in place where is not even, make sure there is nothing flammable or easy deform object within 1 meter (36 inches).
- 2) Insert the plug after setting the thermostat to "MIN" position and setting the power selected switches to "0" position.
- 3) Do not cover the unit.
- 4) The heater is suitable for operation on an A.C. electricity supply having the same voltage as that show on its rating label.

Rotate power switch to the "3" position then turn thermostat to the "Max" position, at this moment, the unit begins to work, when the temperature rises to which you are satisfied with, slowly turn the thermostat counter clockwise until the indicating light of the key for power choice is out, and the room temperature thus can keep constant.

If you want to raise or lower the room temperature, you can make another regulation: Turn the thermostat clockwise to raise the temperature and counterclockwise to lower it.

4. After use, turn the power switch to the "0" position first, then turn the thermostat to the "MIN" position, and pull out the power supply plug.

Thermostat**Output selector**



Waste treatment

This appliance is marked in accordance with EU Directive 2014/30/EU, 2014/35/EU and 2012/19/EU regarding the handling of electrical and electronic waste (Waste Electrical and Electronic Equipment - WEEE). Make sure that this product is disposed in the correct manner, so that it does not constitute a health or environmental risk.



— The symbol on the product or on the documents accompanying the product, indicates that this product may not be treated as household waste. Handing it over to a authorized for the recycling of electrical and electronic equipment. Pick must be in accordance the local waste regulations. For further information treatment, recovery and recycling of this product, contact your local council, waste disposal service or the shop where you purchased it.

BEHA

BEHA ELEKTRO AS, 3940 PORSGRUNN

Tlf.: 35 51 62 50 Fax: 35 51 62 60 Ordre: 35 51 62 70

e-post: post@beha.no

www.beha.no